




T O P S K Y

TS500021



DO NOT RETURN !!!

Please contact our service team with Order-ID. And if that is possible, pictures or detail of issue will be helpful for a fast way solution.


service@topskyfurniture.com
Phone number: +1 725-333-1988

Special Warnings


- Ø Keep your furniture out of direct sunlight. Please use desk pads and coasters to protect the surface from dents, scratches, and moisture from hot or cold liquids.
- Ø For cleaning, wipe the surface with a damp (not wet) cloth or wipe dry with a clean lint free cotton cloth. Window cleaning liquid or a similar cleaning liquid can be used to clean glass surface.

Operation Instructions

- Ø Please check that all parts are present before you start the assembly of your furniture. For the protection of your furniture, place all parts on a clean and smooth surface to prevent any damage.
- Ø Please periodically check all fitting and re-tighten as necessary.
- Ø Please assemble the table by 2 persons or more.
- Ø Do NOT over tighten hardware.




Part.	Item.	QTY.	
A	M10X70	8	
B	M8X70	4	
C	φ11	8	
D	φ11	8	
E	Allen Key	1	
F	Allen Key	1	



1

.SCREWS		.SCREWS	
A	M10X70	C	φ11
	8 PCS		8 PCS
.SCREWS		.SCREWS	
D	φ11		
	8 PCS		

WARNING: Please do not put your hand in the gap between the steel pipe and the board to avoid injury.



2

.SCREWS	
B	M8X70
	4 PCS

