



90cmm



1 "GloryFit" APP download Scan the QR code on the left to download the APP
 Install the APP,please register and login according to the interface prompts *Compatible: IOS10.0 or above/ Andriod5.0 or above. 2 Power ON Press and hold the upper button for 5 seconds to turn on Power OFF Press and hold the upper button for 3 seconds to turn off 3 Set up and pair \bigotimes 1. Turn ON the Bluetooth in your smartphone 2. Open the GloryFit, go "Device", "+ Add a new device" 3. Search Bluetooth device & Select the "FutureGo Flex" fo Add a new device binding On home screen Swipe down to enter the main menu Swipe up to enter the massages Swipe left to enter activity data Swipe right to enter heart rate, blood oxygen.. \bigcirc Ŕ 0 🔀 Exercise data can view steps, distance, calories The phone's information will be synced to the watch \bigcirc Health monitoring: heartrate, blood oxygen, sleep Θ Enjoy more on FutureGo Flex 6, \odot Θ Θ Sports mode

🗷 Click the button to switch sports mode

FutureGo Flex Product parameter Packing list FutureGo Flex Watch x 1 Charging Cable x 1 Quick Start Guide x 1 Waterproof rating: IP68 Waterproof Sensor: 3axisG-sensor Sensor: 3axisG-sensor Battery capacity: 330mAh Synchronization method: Bluetooth Resolution: 360* 360 pixels Display screen: 1.32 inch TFT - LCD Working time: about 7-15 days Working temperature: -10C~50°C Compatible system: IOS 10.0 or above, Android 5.0or above **Regulatory Information** To view regulatory information, please go to Settings-About-Regulatory Information Note Please read the instructions before use: The company reserves the right to modify the content of this notice without notice. According to normal circumstances, some functions are different in specific software versions. versions.
The product should be charged for more than 2 hours before use, but avoid prolonged charging in an unmanned environment when charging.
Please attach the magnetic charging cable to the charging port of the bracelet automatically.
Please use the input voltage: 5V/1A or 5V/2A charging head, with the original charging cable provided by the manufacturer.
Before using the product, please download the login application to the mobile phone, which can use the wristband time to set personal information. Precautions Please read this manual first to ensure safe and correct use. The data of this product is for health management reference only.
Please do not use it as medical data. If any abnormal body data is found, it should be subject to hospital testing.
The waterproof rating of the watch is IP68 Waterproof.
You can use it normally in life situations such as handwashing, raining, etc. Please do not put the watch in hot water, do not perform operations such as underwater pressing or deep diving, and do not expose the watch to corrosion Sexual liquid to prevent damage to the watch. Warranty Card Customer Information: Туре Seller Seller Tel Customer _____ Purchase Date Customer Tel _____ Customer Address _____ Seller Address Abstract: Date Fault ____

Malfunction

Limited Warranty

Remarks

Note: Disassembling device voids warranty

